

David-Link

W-988



USER'S MANUAL

TABLE OF CONTENTS

1 GENERAL INFORMATION.....	1
1.0 Notification.....	1
1.1 System overview.....	1
1.2 Main Features.....	1
1.3 Equipment.....	2
2 SYSTEM SUMMARY.....	3
2.1 System Configuration.....	3
2.1.1 Model Selection.....	3
2.1.2 Terminal Communication Ports.....	3
2.1.3 Keypad Function.....	4
2.1.4 External Overview.....	4
2.2 Menu Tree Chart.....	5
3 GETTING STARTED.....	11
3.1 Start-up.....	11
3.2 Fingerprint Enrollment Tips.....	11
3.2.1 Correct Finger Positioning.....	11
3.2.2 Incorrect Finger Positioning.....	12
3.2.3 Tips for Improving Fingerprints Reads.....	12
3.3 Register.....	13
3.3.1 Register User/Admin by Fingerprint.....	13
3.3.2 Register User/Admin by Password.....	14
3.3.3 Register User/Admin by Proximity Card (Optional Function).....	15
3.4 Delete user.....	16
3.5 Set Time and Date.....	17
3.6 Set Communication.....	17
3.6.1 USB download.....	17
3.6.2 RS232 download.....	18
3.6.3 RS485 download.....	18
3.6.4 Ethernet download.....	18

4 ADVANCED SETTING.....	22
4.1 Device Setting.....	22
4.2 Record Setting.....	23
4.3 Lock Control (Additional Access Control Box Required).....	23
5 INFORMATION.....	24
5.1 Storage Detail.....	24
5.2 Record Detail.....	24
5.3 System Detail.....	25
6.0 Troubleshooting.....	26
6.1 Q. & A.....	26
6.2 Fingerprint Privacy.....	26

FCC WARNING:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantees that interference will not occur in a particular installation. Residential installation of this equipment may cause harmful interference in which case user is encouraged to correct the interference at his or her own expense.

CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1 GENERAL INFORMATION

1.0 Notification

Do not attempt to service the terminal yourself. Opening the terminal will void your 1-year manufacturer's limited warranty. Please always follow the instructions in this user's manual.

1. Do not place the terminal in direct sunlight. Bright light may significantly affect fingerprint reads. The terminal is designed for indoor use within a temperature range of 32-104° F (0-40° C). Keep the terminal away from heat sources.
2. This terminal is intended to be used as employee Time & Attendance System. Do not use this terminal for other purpose such as access control system. The terminal warranty does not cover defects or damages arising from improper installation, improper storage, abuse, ordinary wear-and-tear or unauthorized service.
3. Please save your data and records in USB thumb drive or in your computer periodically. David-Link is not responsible for any lost data and records from the terminal and software.

1.1 System Overview

W-988 is a Time & Attendance system designed for small to medium size businesses with up to 300 employees. W-988 verifies an employee's identity based on individual's matching fingerprint. Your business will also reduce costly payroll and data entry errors caused by the old time card system and accounting staff's calculations by hand.

1.2 Main Features

- User friendly menu interface
- DL Time Management Software included
- Standalone device
- Easy USB downloads for data and records
- Fingerprint/password/proximity card (optional) punch
- Variable security threshold
- Fingerprint capacity: 3,000
- Transaction storage: 50,000 log records
- Communication: RS485, TCP/IP, USB

- Verification: 1:1 or 1:N
- FAR < 0.0001%
- FRR < 1%
- Matching speed: <1 second
- Language: English, Chinese, Japanese, Spanish
- Operating voltage: DC 9V
- Operating temperature: 32 ~ 104 °F
- Backup battery (optional)
- Door access control available upon request
- 1 year limited Manufacturer Warranty Included

1.3 Equipment

W-988 package includes:

- 1x W-988 Terminal
- 1x User's Manual
- 5x Proximity Badges (W-988P and W-988PB)
- 1x Software CD
- 1x AC/DC Adapter
- 1x Wall Mounting Kit
- 1x USB Flash Drive

2 SYSTEM SUMMARY


2.1 System Configuration

2.1.1 Model Selection

Three levels are available in David-Link Model W-988. Please see the table below for comparison:

Model No.	Description
W-988	David-Link Biometric Time & Attendance System
W-988P	David-Link Biometric Time & Attendance System with Additional Proximity Badge Verification Method
W-988PB	David-Link Biometric Time & Attendance System with Additional Proximity Badge Verification Method and Built-in Backup Battery

2.1.2 Terminal Communication Ports



Bottom of Terminal


Port	Connect by	Connect to
DC	Power Supply	Outlet
COM 1	RS 232 RS485	PC
COM 2	TCP/IP	PC or Router
USB Serial	USB Cable	PC

2.1.3 Keypad Function


1	2	3	ESC
4	5	6	MENU
7	8	9	▲
•	0	OK	▼


ESC	Back to the last page
MENU	Enter Setting mode
OK	Confirm setting
▲	Move up
▼	Move down
0-9	Number key
•	Power ON/OFF (press and hold)


2.1.4 External Overview





2.2 Menu Tree Chart














3 GETTING STARTED

3.1 Start-up

Press the power button [•] to turn on the terminal. The Start-up window will appear as the following:



Press and hold the power button [•] for 2 seconds to turn off the terminal


3.2 Fingerprint Enrollment

Tips: It is recommended that you enroll at least 2 fingerprints in the terminal in the event that if one of the fingerprints is injured or damaged, you can always punch in/out using the other finger. Each user can enroll 1 to 10 fingerprints in the terminal.


W-988 will require an user to press each finger 3 times to successfully enroll the user. Place your finger in the middle of the sensor. To ensure better fingerprint reads, each time press the finger flat and firmly on the center of the sensor surface and cover as much of the sensor surface as possible.

3.2.1 Correct Finger Positioning:


Place finger flat on the center of sensor surface




3.2.2 Incorrect Finger Positioning:




Vertical



Offset



Inclined



Lower

3.2.3 More Tips for Fingerprint Reads


	Correction
Dirty or Dry Finger	Clean finger with moisturizing soap or wipe (alcohol-free wipes preferably).
Not enough pressure	User should place finger firmly and flat on the sensor surface.
How to select finger?	It is recommended that you enroll the index or middle finger. We also recommend you to enroll your fingerprints using the left hand fingers as their fingerprints are usually less worn or damaged than the right hand fingerprints.

How to position the finger?	Place finger flat with pressure on the center of the sensor surface; DO NOT touch the sensor in an angled or tilted position, DO NOT slide your finger.
Fingerprint pattern change	The verification process can be affected if an user punch in/out with a worn or injured finger. Use an alternate finger or select 1:1 verification mode.
Others	Very few people's fingerprint quality is too poor to be verified. Use User ID & Fingerprint verification method, or lower the 1:1 Threshold. Otherwise use Password or Proximity Card Verification Method (available in model W-988P and W-988PB)

3.3 Register

3.3.1 Register User/Admin by Fingerprint

1) Press [MENU], select "Register", press [OK], select "User", press [OK]. Five enrollment methods are displayed, select "Enroll FP", press [OK]. The following appears:



2) The terminal automatically suggests an available User ID number to you in sequence. Input the desired User ID number (range is 1 to 65534) and press [OK]. The following appears:



3) You will be prompted to press your finger (3) times for better collection of your fingerprint data. If the test is successful in all three times, the following appears:

```
Reg Finger
ID 00000001
Enroll OK
```

4) Press [**OK**] to enroll a new user or press [ESC] to exit.

3.3.2 Register User/Admin by Password

1) Press [**MENU**], select “Register”, press [**OK**], select “User”, press [**OK**]. Five enrollment methods are displayed, select “Enroll Password”, press [**OK**]. The following appears:

```
Reg Password
ID 00000001
ESC-ESC  SET-OK
```

2) The terminal automatically suggests an available User ID number to you in sequence. Input the desired User ID number (range is 1 to 65534) and press [OK]. The following appears:

```
Reg Password
ID 00000001
PWDIN *****
ESC-ESC  SET-OK
```


3) You will be required to input a set of password combination with up to 8 digits twice and press[OK]. The following appears:

```
Reg Password
ID 00000001
Enroll OK
```


4) Press [**OK**] to enroll a new user or press [**ESC**] to exit.

3.3.3 Register User/Admin by Proximity Card (Function Available in Model W-988P and W-988PB)

1) Press [**MENU**], select “Register”, press [**OK**], select “User”, press [**OK**]. Five enrollment methods are displayed, select “Enroll ID Card”, press [**OK**]. The following screen is displayed:



2) The terminal automatically suggests an available User ID number to you in sequence. Input the desired User ID number (range is 1 to 65534) and press [**OK**]. The following appears:




3) Place your ID card in front of the terminal (the sensor is located above the fingerprint sensor surface) and press [**OK**].

*Your ID card does not have to be in direct contact with the terminal. The sensor can detect the ID card within a distance range of 2" to 6" in front of the terminal.

4) Press [**OK**] to enroll a new user or press [**ESC**] to exit.

3.4 Delete user

1) Press [**MENU**], select “Delete”, press [**OK**], the following appears:




```

Delete
ID    00000001
ESC-ESC  SET-OK

```

2) Input the User ID, press [**OK**] to confirm. Follow the prompts to delete user.

Note: Each time an user is deleted, the terminal deletes only 1 fingerprint or password. If an user is registered with multiple fingerprints, the Delete process has to be repeated until all registered fingerprints and passwords are deleted. For example, if an user with 2 registered fingerprints is to be deleted, during the first Delete process, an user's first registered fingerprint will be deleted. The following appears for confirmation of deleting first registered fingerprint and Press [OK]:




```

Delete
00000001-0
Sure Delete?
ESC-ESC  SET-OK

```

After pressing [OK], the second registered fingerprint is automatically shown as the following for the confirmation of deleting second registered fingerprint:



```


Delete
ID    00000001-1
ESC-ESC  SET-OK

```

Continue to press [OK] until all registered fingerprints are deleted.

3.5 Set Time and Date

1) Select “Date Time”, press [OK]. The following appears:

A screenshot of a terminal window with a blue background. The text displayed is: 2009-12-05, 01:18:44, THU, and ESC-ESC Con-OK.

2009-12-05
01:18:44
THU
ESC-ESC Con-OK


2) To change date & time, input the correct date, press [▲/▼], enter the time and press [OK].

Note: The time and date can be updated by pressing [Time Sync] in [Download] menu when connecting with Time Management Software.

3.6 Set Communication


3.6.1 USB download

1) Press [MENU], select “Data Download”, press [OK], the following appears:

A screenshot of a terminal window with a blue background. The text displayed is a numbered list: 1. USB Download, 2. RS232 Dwnld, 3. RS485 Dwnld Yes, and 4. Ethernet Dwnld.

1. USB Download
2. RS232 Dwnld
3. RS485 Dwnld Yes
4. Ethernet Dwnld

2) Press [1] to select USB download (make sure the USB thumb drive is already plugged into the terminal), one of the following windows appears:

A screenshot of a terminal window with a blue background. The text displayed is a numbered list: 1. All Logs & Del, 2. All Logs, and 3. All EnrollData.

1. All Logs & Del
2. All Logs
3. All EnrollData

	Description
All Logs & Del	Allows you to transfer all attendance records to USB thumb drive and delete all records saved in the terminal.
All Logs	Allows you to only transfer all attendance records to USB thumb drive (without deleting records saved in the terminal).
All Enroll Data	Allows you to transfer all employee data including ID numbers, fingerprint templates, proximity cards, and password to USB thumb drive. This serves as a purpose that if there are multiple terminals in one work place, transferring all employee information to another terminal via USB thumb drive eliminates the need of having employees to register with multiple terminals.

3) Select Glog, All Glog or All enroll Data and the USB thumb drive will download the records directly from the terminal, the following appears:



(Note: do not remove USB drive while downloading)

The following communication methods are used to connect with David-Link Time Management Software.

3.6.2 RS232 download

Not Available

3.6.3 RS485 download

- 1) Press **[MENU]**, select "Data Download", press **[OK]**, press [3] to select RS485 download
- 2) Enter baud rate and press [OK].

3.6.4 Ethernet download

- 1) Press [4] to select Ethernet download, the following appears:

1. IP Address
2. Subnet mask
3. Default Gateway
4. Port no.
5. Server IP
6. Server Port No.
7. Server Req.

2) Configure the Ethernet setting according to your computer network setting.

3) There are 2 ways to connect the terminal with David-Link Time Management Software using Ethernet connection. It is recommended that you follow the setting below:

Terminal-to-PC Connection	Plug network cable into COM2 port on the bottom of the terminal and the appropriate Ethernet port on your computer.
Terminal-to-Hub Connection	Plug network cable into COM2 port on the bottom of the terminal and the appropriate hub in your network.

Terminal-to-PC Connection:

(a) On your computer, go to "Local Area Connection", right click and select "Properties", Click on "Internet Protocol Version 4 (TCP/IPv4)" and select "Properties". It is recommended to input the IP address as **192.168.1.200** and leave everything else as it is.

(b) On your terminal, Set IP Address as **192.168.1.201** and leave everything else as it is.

(c) To test the connection, plug network cable into COM2 port on the bottom of the terminal and the appropriate Ethernet port on your computer. On your computer, Ping the terminal by inputting ***ping 192.168.1.201 -t*** (For Microsoft® Windows XP, Windows VISTA, and Windows 7, you can ping the terminal by inputting the above information in the *Search* box once you click **Start** menu). If connection is made, the following appears:

```

C:\Windows\system32\ping.exe

Pinging 192.168.1.201 with 32 bytes of data:
Reply from 192.168.1.201: bytes=32 time=82ms TTL=128
Reply from 192.168.1.201: bytes=32 time=53ms TTL=128
Reply from 192.168.1.201: bytes=32 time=7ms TTL=128
Reply from 192.168.1.201: bytes=32 time=162ms TTL=128
Reply from 192.168.1.201: bytes=32 time=124ms TTL=128
Reply from 192.168.1.201: bytes=32 time=87ms TTL=128
Reply from 192.168.1.201: bytes=32 time=49ms TTL=128
Reply from 192.168.1.201: bytes=32 time=12ms TTL=128
Reply from 192.168.1.201: bytes=32 time=167ms TTL=128
Reply from 192.168.1.201: bytes=32 time=129ms TTL=128
Reply from 192.168.1.201: bytes=32 time=91ms TTL=128
Reply from 192.168.1.201: bytes=32 time=50ms TTL=128
Reply from 192.168.1.201: bytes=32 time=10ms TTL=128
Reply from 192.168.1.201: bytes=32 time=165ms TTL=128

```

d) Open your David-Link Time Management Software (DLTMS), select "Download", click on "Setting" and input the appropriate Device ID and IP address stored in the terminal (make sure the appropriate terminal is selected).

Terminal-to-Hub Connection

(a) On your computer, double-click on "Local Area Connection" and select "Details" to check your network IP Address.


(b) On your terminal, input the IP Address as the following:

XXX . XXX . X . YYY

IP Address	Terminal IP Address
XXX . XXX . X.	The first 3 sets of IP Address to be stored in the terminal should be identical as the first 3 sets of IP Address in you network.
YYY	The last set of IP Address to be stored in the terminal should be a 3-digit unique value. It strongly recommended that the last set of IP address to be stored in the terminal should be at least 201 and up.

(c) To test the connection, plug network cable into COM2 port on the bottom of the terminal and the appropriate hub in your network. On your computer, Ping the terminal by inputting ***ping your terminal IP address -t*** (For Microsoft® Windows XP, Windows VISTA, and Windows 7, you can ping the terminal by inputting the

above information in the *Search* box once you click **Start**). If connection is made, the following appears:



```
C:\Windows\system32\ping.exe

Pinging 192.168.1.201 with 32 bytes of data:
Reply from 192.168.1.201: bytes=32 time=82ms TTL=128
Reply from 192.168.1.201: bytes=32 time=53ms TTL=128
Reply from 192.168.1.201: bytes=32 time=7ms TTL=128
Reply from 192.168.1.201: bytes=32 time=162ms TTL=128
Reply from 192.168.1.201: bytes=32 time=124ms TTL=128
Reply from 192.168.1.201: bytes=32 time=87ms TTL=128
Reply from 192.168.1.201: bytes=32 time=49ms TTL=128
Reply from 192.168.1.201: bytes=32 time=12ms TTL=128
Reply from 192.168.1.201: bytes=32 time=167ms TTL=128
Reply from 192.168.1.201: bytes=32 time=129ms TTL=128
Reply from 192.168.1.201: bytes=32 time=91ms TTL=128
Reply from 192.168.1.201: bytes=32 time=50ms TTL=128
Reply from 192.168.1.201: bytes=32 time=10ms TTL=128
Reply from 192.168.1.201: bytes=32 time=165ms TTL=128
```

d) Open your David-Link Time Management Software (DLTMS), select "Download", click on "Setting" and input the appropriate Device ID and IP address stored in the terminal (make sure the appropriate terminal is selected).

4) Press [Esc] to exit and [Ok] to save changes.

4 Advanced Setting

4.1 Device Setting

1) Press [**MENU**], select “Advanced Setting”, press [**OK**].

2) Select “Device Setting”, the following appears:

1. Machine ID
2. Admin Qnty
3. Language
4. Voice Out
5. Volume

6. Contrast
7. Auto Off
8. Pkey Use
9. Verify
10. Default Setting

Setting	Description	Default Setting
1. Machine ID	Machine ID is needed when connecting to the computer. When multiple terminals are in the same network, Machine ID has to be different from one another.	1
2. Admin Qnty	Number of administrators allowed to register in the terminal (1 ~ 10).	5
3. Language	Change device language. Support: English, Spanish, Japanese, Chinese Simplified and Chinese Traditional	English
4. Voice Out	Turn on/off the sound from the terminal	YES
5. Volume	Set Terminal Volume (1 ~ 10).	8
6. Contrast	LCD contrast setting (1 ~ 63)	53
7. Auto Off	Automatically turn off the terminal when there is no activity detected within # minutes (1~ 255).	NO
8. Pkey Use	Turn On/Off the use of power button. [•]	YES
9. Verify	Verify user by fingerprint, ID card, and/or password. Select from: F/P/C : fingerprint, password, or ID card verification. C+P : both ID card and password verification (available in Model W-988P and W-988PB). F+P : both fingerprint and password verification. F+C : both fingerprint and ID card verification (available in Model W-988P and W-988PB). C : ID Card verification (available in Model W-988P and W-988PB). P : Password verification.	F/P/C
10. Default Setting	Restore device to factory default settings, and all current settings will be lost. Please save your data and records before pressing this button.	

3) Press [**Esc**] to exit and [**Ok**] to save changes.

4.2 Record Setting

- 1) Press [MENU], select “Advan Setting”, press [OK].
- 2) Select “Record Setting”, the following appears:

1. ARec Wrn	NO
2. URec Wrn	1000
3. Reverify	NO

- 3) Press [1] or [2] to set the warning when the terminal's memory capacity can only save # more log records before the memory is full. (Enter the number of log records to remind you of the terminal's memory capacity approaching to its limit). [1]: number of Administrator's records for reminder warning; [2]: number of User's records for reminder warning.
- 4) Press [3] to set number of minutes before an user's another punch is accepted by the terminal. This function serves the purpose to avoid duplicate punches (Enter # of minutes from 1-255).

4.3 Lock Control (Additional Access Control Box Required)

Not Available

Note: This product is intended for use as a Time & Attendance System. Installing this product as an access control system will void the warranty. David-Link is not responsible for any damage or defect caused by misusing this terminal as an access control system. Please contact us for information about access control system.

5 Information

5.1 Storage Detail

- 1) Press [MENU], select “Information”, press [OK].
- 2) Select “Storage Detail”, the following appears:

1. User Reg
2. Manager Reg
3. Finger Reg
4. PW Reg
5. ID Card

	Description
1. User Reg	View number of users registered in the terminal
2. Manager Reg	View number of Administrators registered in the terminal
3. Finger Reg	View number of fingerprints enrolled in the terminal
4. PW Reg	View number of password combinations stored in the terminal
5. ID Card	View number of ID cards registered in the terminal

5.2 Record Detail

- 1) Press [MENU], select “Information”, press [OK].
- 2) Press “Record Detail”, the following appears:

1. User Rec
2. Admin Rec
3. View User Rec
4. View Admin Rec
5. Delete All Rec

	Description
1. User Rec	View number of user's log records saved in the terminal.
2. Admin Rec	View number of administrator's log records saved in the terminal.
3. View User Rec	To view a specific user's log records, input the user's ID number and press [OK] to view.
4. View Admin Rec	To view a specific administrator's log records, input the administrator's ID number and press [OK] to view.
5. Delete All Rec*	Delete all log records in the terminal

**David-Link is not responsible for any lost data and record. Please make sure you save all your data and records in a safe place. Log records cannot be recovered after you delete all log records saved in the terminal.*

5.3 System Detail

- 1) Press [MENU], select “Information”, press [OK].
- 2) Select “System Detail”, the following appears:

1. Manufacture
2. Device Name
3. Release Time
4. Serial Number
5. Engine Version
6. Software Version

Here, you can find our company information and contact method within the [Manufacturer] function. Please also find your [Serial Number], [Firmware Version] and [Software Version] here when we ask for the information.

- 3) Press [ESC] to exit.

6 Troubleshooting

6.1 Q. & A.

Q: Fingerprint cannot be verified.

A: Possible Causes:

- 1) Fingerprint is damaged or smooth;
- 2) Finger is dry.

Q: What is the standard warranty on biometric time clocks?

A: The standard warranty on a biometric time clock is a period of 1 year from the date of original purchase from David-Link or an Authorized David-Link Reseller. However, there are things that the warranty does not cover. Please read the Certificate of Warranty carefully for the parts that the warranty does not cover.

Q: How do I remove an Admin User?

A: Only an Admin user can add/remove an user on the device.

Q: Device cannot be turned on. Is it a defective product?

A: Please make sure the power adaptor is plugged into the outlet and the device. If the device still cannot be turned on after the power adaptor is correctly plugged, please contact David-Link Technical Support Team at 888.755.9418.

Q: How do I get replacement parts such as ribbon cassettes or backup batteries?

A: Please visit our website: www.davidlinkusa.com or contact us at 1.888.755.9418 to get information about ordering replacement parts.

6.2 Fingerprint Privacy:

1. The W-988 merely captures points of the fingerprint but not the actual fingerprint image.
2. The fingerprint points cannot be used to create a fingerprint image.
3. David-Link will not be liable for any direct or the indirect damages resulting from the use or inability to use our equipment.
4. If you have a question about privacy concerning the use of our equipment you should have your employer contact David-Link.

